

# Exercises: Importing and Visualizing Videos

**AUVSI Foundation: Computer Vision Training** 



### Video File Import

The vipwarnsigns avi video shows a camera mounted on a vehicle viewing traffic signs as the vehicle moves around. In this exercise, you will view this video using MATLAB®.

- 1. Create a video file reader system object to read this video file.
- 2. Set the output color space to RGB.
- 3. Set the output data type to uint8.
- 4. Create a deployable video player object to view the video.
- 5. Acquire frames using the video file reader and display them in the video player until all the frames have been read.

#### Solution

>> importVideoFile



## Video Camera Acquisition

In this exercise, you will use a camera to acquire video frames and display them in MATLAB.

- 1. Create a VideoDevice System object.
- 2. Determine the list of available video formats.
- 3. Set the returned video format to 640-by-480, or the closest available resolution.
- 4. Set the output data type to uint8.
- 5. Create a deployable video player object to view the video.
- 6. Acquire frames for 10 seconds and display them in the video player.

#### Solution

>> acquireVideoCamera





